

#### WARNING AND SAFETY INSTRUCTIONS:

Do not attempt to repair your mouse: Do not attempt to disassemble, open, repair or alter the product, its accessories, or the power cable. You could electrocute yourself or expose yourself to other hazards. Any signs of attempts to open and/or alter this device, including removing or tearing a sticker, will void the warranty. Use near a liquid: To reduce any risks of fire or electric shock, do not use this device in the vicinity of a liquid and do not expose it to rain or moisture. Do not attempt to dry the device with a hair-dryer or microwave oven. Risk of asphyxiation: this device may contain small parts, plastic bags or packaging that could represent a risk of asphyxiation for children. Keep all small parts, bags and packaging out of the reach of children.

#### Charging-related risks, leads/cables:

- . Store all cables and leads in such a manner that there is no risk of persons or animals accidentally tripping on them or pulling them when moving around the area where the device is located. Do not allow children to play with the cables and leads.
- . To avoid any damage to the power cables and the power supply:
- . Protect the electrical cables in such a manner that no-one can tread on them.
- . Protect the electrical cables from pinching or excessive bending, in particular when connected to the power plug, power supply unit, or the device.
- . Do not pull abruptly on the power cables, do not bend them too tightly and do not mistreat them in any other way.
- . Do not expose the power cables to heat sources.
- . Keep the power cables out of the reach of children and animals. Do not allow them to bite or chew them.
- . When disconnecting the power cables, pull on the plug. Do not pull on the cable.
- . If a power cable or power supply unit is damaged in any way, stop using it immediately.
- . Disconnect your device during storms or if not used for extended periods of time.
- . For devices provided with a mains power cable that connects to the power supply unit, always follow the instructions hereafter when connecting the power lead: connect the mains power cable to the power supply unit by fully engaging it, then connect the other end of the mains lead to the wall outlet.

#### WARRANTY:

Because your satisfaction is our prime concern, each EMPIRE GAMING product has a unique serial number! You will be asked for this number, along with your invoice, when you contact the After-Sales & Warranty service of our authorised EMPIRE GAMING reseller. EMPIRE GAMING products are guaranteed 1 year from date of purchase. Keep your invoice safely, we recommend stapling it to your user guide. Failure to observe the safety instructions, along with any signs of attempts to open and/or alter this device and its cables/leads, including removing or tearing a sticker, will void the warranty.

#### EMPIRE GAMING AND THE ENVIRONNEMENT:



EC declaration of compliance: EMPIRE GAMING declares that this product conforms to the main requirements and other provisions of the applicable EC directives.



WEEE (Waste Electrical and Electronic Equipment): the use of this symbol indicates that this product may not be treated as household waste. By disposing of this product in accordance with applicable regulations, you help avoid any potentially negative effects on the environment and on human health. For further information on the recycling of this product, please contact your local household waste collection and recycling service.



Moebius strip: you have all seen this logo on our packaging materials. But what does it actually mean? It means that the product and its packaging are recyclable. The easiest way to protect our environment is to recycle! Become an eco-responsible eco-citizen with EMPIRE GAMING.



RoHS (Restrictions of Hazardous Substances) standard: this is a European environmental directive restricting the use of environmentally hazardous substance in all electronic products. This directive applies to all electronic and electrical equipment using an electrical or electromagnetic field. In order to reduce the use of hazardous substances in the manufacture of our products, EMPIRE GAMING undertakes to offer you the best technology in an environmentally respectful manner.

**MODEL: OE-KM-156**

S/N:

 **EMPIRE**  
**MK800**



## ANTI-GHOSTING / WINDOWS LOCK

Les 19 touches bénéficiant de la fonction Anti-Ghosting sont :

[A], [Z], [E],  
[Q], [S], [D],  
[W], [X], [C], [B]  
[▲], [▶], [▼], [◀]  
[Espace], [Tab], [Shift]\*, [Alt]\*, [Ctrl]\*

\* : pour ses 3 touches, il s'agit de celles situées à gauche de votre clavier !

Pour activer le mode [Play], désactivation des touches Windows® : appuyez sur [Fn] + [Windows].

Pour activer le mode [Office], activation du menu contextuel Windows® : réitérez la combinaison ci-dessus

## MULTIMEDIA

Ci-dessous la liste des fonctionnalités disponibles, en effectuant la combinaison de touches : [Fn] +

[F1] = Ouverture de votre Mediaplayer  
[F2] = Diminuer le volume  
[F3] = Augmenter le volume  
[F4] = Mode mute (silence)  
[F5] = Stop  
[F6] = Piste précédente  
[F7] = Lecture / Pause  
[F8] = Piste suivante  
[F9] = Ouverture de votre messagerie  
[F10] = Ouverture de votre navigateur web  
[F11] = Bloquer le touches du clavier  
[F12] = Ouverture de la calculatrice

## RGB

Pour activer/désactiver le mode :

- [LED Multicolore Fixe], appuyez sur les touches [Fn] + [✳]
  - [Mode Breathing], appuyez sur les touches [Fn] + [✳]
- Pour augmenter la luminosité, appuyez sur les touches [Fn] + [Pg Up / Etoile +]  
Pour la diminuer : [Fn] + [Pg Down / Etoile -]

Pour éteindre le rétroéclairage, appuyez sur la touche [✳]

## SOURIS EMPIRE GAMING

Souris 6 Boutons + Molette de défilement bidirectionnelle  
Capteur optique infrarouge, résolution max 2400 DPI  
Changement de résolution à la volée : 800 / 1200 / 1600 / 2400 DPI  
Accélération : 8 g  
Vitesse de déplacement : 125 ips  
Vitesse de transfert USB : 125 Hz  
Rétro-éclairage RGB  
Patins anti-frottements pour une glisse parfaite